

# Rainman Auto Remote Micropanel – Quick Reference

Start

Press START once

Set Timer

Press/hold START up to 6 seconds  
LED flashes indicates 1, 2, or 3 hour timer

Stop


Press STOP once

Reset Faults

Press/hold STOP for 4 seconds  
LED's flash



Manual Override



Download  
IOS/Android app  
From app stores to  
control  
and monitor Rainman



Full User Guide

# Rainman Micropanel – LED Quick Reference

## Normal Operations

Run	Water	Flush	Status
			System off
			Ready to operate
			Making water - Divert
			Making water - Tank
			Shutting down
			Fresh water flushing
			Attempt start when tank full

## Fault Conditions

Run	Water	Flush	Condition
			Warning - Salinity
			Warning – Flow rate
			Fault - Salinity
			Fault - Low pressure
			Fault – High pressure
			Fault – Flow rate
			Fault - Shutdown
			Fault - Autoflush
			Fault – HP Sensor

## Sample Key



10 rapid flashes



3 slow flashes



Continuous slow flashing



Solid red, amber, or green



Alternating green and yellow